

## Mounting the brackets

1. Dismount the top cover using a 5 mm Allen key.
2. Slide in the square reinforcement (note the holepattern)
3. Mount both brackets(note the bracket angle)by sliding the threads thru the holes and mount the washer and nut inside.

**NB. With only 1 bracket installed, use 2 pcs. M10x35 bolts**

4. Use a 17mm socket-wrench to tighten the bolts with torque 35 Nm.
5. Pull the cables for the luminaires.
6. Mount the top cover.

